



## **list of Configuration Settings for Running under Windows XP.**

### **Automatic Updates**

Turn Off Automatic Updates

Control Panel

Automatic Updates

Turn Off Automatic Updates

Apply

### **Auto Restore**

Turn Off Auto Restore

Control Panel

System

System Restore

Check Turn Off System Restore

Apply

### **Network Protocols**

Disable All Protocols for the Network card used to control the Maccor tester

Control Panel

Network Connections

Properties (Maccor Network Card)

Uncheck all Protocol boxes

Systems with Ethernet Chambers will need TCP/IP Address: 192.168.50.40

Apply

### **Network Card Firewall**

Turn Off Firewall to the Maccor Network Card

Control Panel

Network Connections

Properties (Maccor Network Card)

Advanced

Settings

Advanced

Uncheck (Disable Firewall) for the Maccor Network Card

Click OK

### **Network Card Power Management**

Disable Power Save to the Maccor Network Card

Control Panel

Network Connections

Properties (Maccor Network Card)

Configure

Power Management

Uncheck box that allows the computer to turn off the Network Card

Click OK